






Séparez légèrement le côté.
Slightly separate the lateral sides.

Faites glisser la carrosserie vers le haut.
Lift the body-shell from the chassis.



3 Comment installer un haut-parleur. How to install a loudspeaker.

- ① Retirer le boîtier du haut-parleur.
Remove the speaker box.
- ② Placez le haut-parleur (15 x 11 mm, 8 Ω) avec les contacts vers le bas et fermez le boîtier du haut-parleur.
Place the loudspeaker (15 x 11 mm, 8 Ω) with the contacts facing down and close the speaker box.

2 Installation de décodeur numérique. Install the decoder.

- ① Retirer la fiche factice.
Remove dummy plug.
- ② Installez le décodeur.
Fit the decoder.

HORNBY HOBBIES
www.hornbyinternational.com

Manufactured by:
Hornby Hobbies Ltd
Westwood, Margate,
Kent, CT9 4JX, UK


EU Authorised Representative:
Hornby Italia SRL
Viale dei Caduti, 52/A6,
Castel Mella (BS), Italy, 25030

FR 0801.87.00.06
Customerservices.fr@hornby.com
Technicalservices.fr@hornby.com

DE 08000.00.26.27
Customerservices.de@hornby.com
Technicalservices.de@hornby.com

UK +44 (0)1843 233525
Customerservices.uk@hornby.com
Technicalservices.uk@hornby.com

CE UK CA 12V 14+



LISTE DE PI  CES DE RECHANGE / LIST OF SPARES

R��f. Item No	Description		R��f. rechange Spare part ref.
1	Sachet de d��tailage de cabine Accessories bodyshell	HJ2603 HJ2604 HJ2605	HJ2600/01 HJ2604/01 HJ2605/01
2	Moteur Motor		HJ2600/02
3	Circuit imprim�� principal PCB		HJ2600/03
4	Sachet de d��tailage de ch��ssis Accessories chassis		HJ2600/04
5	Attelage pack Coupler mechanism		HJ2600/05
6	Bogie moteur complet Complete bogie		HJ2600/06
7	Circuit d'��clairage Light cab and diffuser		HJ2600/07
8	Bandage d'adh��rence Traction tyres		HJ2600/08

Configuration des fonctions d'  clairage en mode num  rique

Avant de l  utiliser cette locomotive dans un syst  me num  rique, vous devez tr  s probablement programmer votre d  codeur en cons  quence (mapping des fonctions).

Configuration of light functions in digital mode

Before to use this locomotive in a digital system, most likely you have to program your decoder accordingly (function mapping).

Output	Function
F0f	Feu avant, (cabine 1) White lights (cabine 1)
F0r	Feu avant, (cabine 2) White lights (cabine 2)
AUX 1	Feu arri��re, (cabine 1) Red lights (cabine 1)
AUX 2	Feu arri��re, (cabine 2) Red lights (cabine 2)