





Apertura della locomotiva
 Demontage der Lokomotive
 Démonontage de la locomotive
 Disassembling the locomotive



Installazione di decoder DCC ed altoparlante
 Einbau des DCC-Decoders und Lautsprecher
 Montage du DCC Decoudeur et haute-parleur
 Installation of DCC Decoder and speaker



LISTA RICAMBI / ERSATZTEILLISTE / LIST OF SPARES

Numero Teil-Nr. Part No.	Descrizione Bezeichnung Description		Cod. ricambio Ersatzteil-Nr. Spare part ref.
1	Set aggiuntivi e respingenti Puffer, Bremsschläuche etc. Buffers and buffer beam details	HL2650	HL2650/01
		HL2651	HL2651/01
		HL2652	HL2652/01
2	Gancio modellistico Kupplungssatz Coupling pack		HR2162/2
3	Carrello motore completo Antriebsdrehgestell, komplett Complete bogie		HR2162/3
4	Guscio carrello con attacco gancio Drehgestellblende mit Kupplung Bogie cover with coupler lock		HR2162/4
5	Guscio carrello senza attacco gancio Drehgestellblende ohne Kupplung Bogie cover without coupler lock		HL2650/05
6	Circuito stampato luci Lichtleiterplatte Lights board	HL2650	HR2162/6
		HL2651, HL2652	HR2076/6
7	Circuito stampato principale Hauptleiterplatte Main PCB board		HL2650/07
8	Confezione motore Motor-Satz Motor Pack		HL2650/08
9	Confezione Albero Universale Universal-Wellensatz Universal shaft pack		HR2162/9
10	Vite senza fine Antriebschnecke Worm gear		HL2650/10
11	Anelli di aderenza Haftreifen Traction Tyres Pack		HR2162/11
12	Set assi motori Radsatz für Antrieb Wheel set (drive unit)		HR2162/13
13	Predellini, dettagli telaio Schritte, Fahrgestell details Steps, chassis details		HL2651/13